

Thank you for choosing Rosetta hardscape products. The following are some helpful tips to make your first installation go smoothly. For more in-depth technical information, see our Rosetta Technical Guide (available at discoverrosetta.com) or contact Bob Conklin with Rosetta Technical Support at (877) 777-6558 ext 3081.

Your safety is important to us. Please follow OSHA guidelines, and utilize safety-toe boots, hardhats, gloves and eye, ear & respiratory protection whenever appropriate.

BLEND MULTIPLE PALLETS

- In order to achieve the best possible color blend, utilize material from multiple pallets simultaneously (when applicable).

PROPER SETBACK

- To achieve proper setback in a retaining wall (4°), place each row of block ¼" back from the previous row. (see graphic on reverse side of this sheet)

AVOID VERTICAL SEAMS

- Lay blocks in a random order to avoid the appearance of vertical seams.

CONVEX RADIUS WALLS

- Convex curved walls can be made with a minimum radius of 14 ft.

GLUE FOR STRENGTH

- For additional wall stability, adhere rows of block together with landscape adhesive.

REQUIRED TOOLS

- PLATE COMPACTOR
- SHOVEL
- RAKE
- LEVEL
- DEAD BLOW HAMMER

OPTIONAL TOOLS:

- TRANSIT LEVEL
- STRING LINE
- CUT OFF SAW
- LANDSCAPE ADHESIVE


OTHER:

- NON-WOVEN GEOTEXTILE FABRIC
- 4" PERFORATED DRAIN PIPE
- GEOGRID


CLAREMONT QUICK INSTALL TIPS

TYPICAL RETAINING WALL SECTIONS


GRAVITY, NON-REINFORCED (0-1 1/4 FT TALL [EXPOSED] WITH NO SURCHARGE)



REINFORCED (GENERALLY 1 1/2 FT TALL AND ABOVE, AS REQUIRED IN THE ROSETTA TECHNICAL GUIDE)



TYPICAL FREESTANDING WALL SECTION



COLUMN INSTALLATION

*Requires Corner Blocks




STEP 1

Place (4) Claremont Corner blocks with the same taper, facing into the center of the pillar.


STEP 2

Place a second row of (4) Claremont Corner blocks with the opposite taper, facing into the center of the pillar.



STEP 3

Continue with subsequent rows to the desired pillar height. One pallet of Claremont Corner blocks will create a 30" x 30" x 40" tall column.



STEP 4

Place a 34" Column Cap on top to finish the pillar. The column cap may be cored as required for the installation of a lamp.